

TS 248XD Snow Accessories



SNOW CHAIN
954 05 02-01



48" SNOW BLADE
588 18 13-02



**42" 2-STAGE SNOW
THROWER (MANUAL)**
967 34 39-01



**42" 2-STAGE SNOW
THROWER (ELECTRIC)**
587 29 37-01

TS 248XD Mower Attachments



40" TOW DETHATCHER
588 19 98-01



42" SWEEPER
529 75 60-01



**130 LB. TOW BEHIND
SPREADER**
588 18 29-04



**10 CU. FT. POLY SWIVEL
DUMP CART**
588 20 88-02

TS 248XD Easy Hitch Attachments



EASY HITCH PLATFORM
588 20 51-01



**EASY HITCH - CURVED
BLADE AERATOR**
588 20 52-01



**EASY HITCH -
PLUG AERATOR**
588 20 52-02



**EASY HITCH - TINE
DE-THATCHER**
588 20 52-03

TS 248XD Mower Accessories



TRACTOR LIFT
585 44 54-01



MULCH KIT
582 55 99-01



36" FRONT SCOOP
588 18 14-01



TRIPLE GRASS COLLECTOR
582 55 96-01